



## STEP 2

- Connect Waist Ring to pegs at the bottom of the Torso Frame.
- Connect Torso Frame to top of legs, with speaker facing back.
- Lift pants over Waist Ring.
- Connect Shoulder Frame to top of Torso Frame. (open space in front, bar in back.)



## STEP 3

- Connect Head to middle of Shoulder Frame.
- Connect wires from Torso Frame to Head.
- Add Brown Short an Plaid Shirt to frame, open side in the back.



## STEP 4

- Connect Arms to Shoulder Frame.
- Add Neck Cover, Hat and Ropes to hands and waist.

## STEP 5

- Remove Plug from box. Go to the back of the Scarecrow, insert plug into jack to the left of the volume knob.
- Insert Step-Pad to the jack on left. (optional)

